

# WILDCAT<sup>®</sup>

# WINCH SERIES

By **RAMSEY  
WINCH<sup>®</sup>**

**OPERATING, SERVICE AND MAINTENANCE MANUAL**



## **WILDCAT 130K MODEL WC 130R 130,000 LB INDUSTRIAL WINCH**



**CAUTION: READ AND UNDERSTAND THIS MANUAL BEFORE  
INSTALLATION AND OPERATION OF WINCH. SEE WARNINGS!**

OM-914267-0715-B

# TABLE OF CONTENTS

WARRANTY INFORMATION	.....	1
SPECIFICATIONS	.....	1
WARNINGS	.....	1
HYDRAULIC SYSTEM REQUIREMENTS	.....	2
CABLE INSTALLATION	.....	3
CLUTCH OPERATION	.....	4
WINCH OPERATION	.....	4
MAINTENANCE	.....	4
LUBRICATION TABLE	.....	5
TROUBLE SHOOTING GUIDE	.....	5
INSTRUCTIONS FOR DISASSEMBLY	.....	6-13
HOSE HOOKUP	.....	14
PARTS DRAWING	.....	15
PARTS LIST	.....	16
AIR CYLINDER	.....	17
DIMENSIONAL DRAWING	.....	18
LIMITED WARRANTY	.....	19

# **RAMSEY HYDRAULIC PLANETARY WINCH MODEL WILDCAT 130K**

## **PLEASE READ THIS MANUAL CAREFULLY**

This manual contains useful ideas in obtaining the most efficient operation from your Ramsey Winch, and safety procedures one needs to know before operating a Ramsey Winch. Do not operate this winch until you have carefully read and understand the "WARNINGS" and "OPERATION" sections of this manual.

## **WARRANTY INFORMATION**

Ramsey Winches are designed and built to exacting specifications. Great care and skill go into every winch we make. If the need should arise, warranty procedure is outlined on the back of your self-addressed postage paid warranty card. Please read and fill out the enclosed warranty card and send it to Ramsey Winch Company. If you have any problems with your winch, please follow instructions for prompt service on all warranty claims. Refer to back page for limited warranty.

## **SPECIFICATIONS\***

APPROXIMATE WEIGHT: .....										2150 LBS	
WORKING PRESSURE: .....										2600 PSI	
CABLE DIAMETER: .....										1.125 INCH	
MAX FLOW: .....										60 GPM	
LAYER OF CABLE	CABLE CAPACITY		LOW SPEED				HIGH SPEED				
			LINE PULL		LINE SPEED		LINE PULL		LINE SPEED		
	Ft	m	Lb	Kg	fpm	mpm	Lb	Kg	fpm	mpm	
1	50	15	130000	58960	16	4.8	60000	27210	34	10.3	
2	110	33	106300	48210	19	5.8	49000	22220	40	12.1	
3	180	54	90000	40820	22	6.6	41500	18820	47	14.2	
4	265	80	78000	35380	25	7.6	36000	16320	54	16.4	
5	360	109	68800	31200	28	8.5	31700	14370	61	18.5	
6	465	141	61500	27890	32	9.7	28400	12880	68	20.6	
*These specifications are based on recommended wire rope 1.125" Extra Improved Steel Cable and a 10.3 cu. in / Rev. Motor.											

NOTE: The rated line pulls shown are for the winch only. Consult the wire rope manufacturer for wire rope ratings.

## **WARNINGS:**

- CLUTCH MUST BE FULLY ENGAGED BEFORE STARTING THE WINCHING OPERATION.**
- DO NOT START WINCH MOTOR BEFORE ENGAGING CLUTCH.**
- DO NOT DISENGAGE CLUTCH UNDER LOAD.**
- STAY OUT FROM UNDER AND AWAY FROM RAISED LOADS.**
- STAND CLEAR OF CABLE WHILE PULLING. DO NOT TRY TO GUIDE CABLE.**
- DO NOT EXCEED MAXIMUM LINE PULL RATINGS SHOWN IN TABLE.**
- DO NOT USE WINCH TO LIFT, SUPPORT, OR OTHERWISE TRANSPORT PEOPLE.**
- A MINIMUM OF 5 WRAPS OF CABLE AROUND THE DRUM BARREL IS NECESSARY TO HOLD THE LOAD.**
- CABLE ANCHOR IS NOT DESIGNED TO HOLD LOAD.**
- BAND BRAKE IS NOT TO BE USED TO HOLD LOAD.**


# HYDRAULIC SYSTEM REQUIREMENTS

## HYDRAULIC SYSTEM REQUIREMENTS



Refer to the performance charts, below, to properly match your hydraulic system to winch performance. The charts consist of:

- (1) Line pull (lb.) first layer vs. working pressure (PSI) and (2) line speed, first layer (FPM) vs. gallons per minute (GPM). Performance based on a motor displacement of 7.0 cubic inches/rev with 60 GPM maximum flow rate. Motor has (2) 1"-12 SAE straight thread o-ring ports.

**Note: A motor spool (open center) directional control valve is required for brake operation.**




## PERFORMANCE CHARTS



BASED ON 10.3 CU IN/REV MOTOR

# CABLE INSTALLATION

1. Unwind cable by rolling it out along the ground to prevent kinking. Securely wrap end of wire rope, opposite hook, with plastic or similar tape to prevent fraying.
2. Place taped end of cable into the hole on the drum flange and bend into the track on drum flange. Secure using supplied u-bolt #73 and (2) nuts.
3. Carefully run the winch in the "reel-in" direction. Keeping tension on end of cable, spool all the cable onto the cable drum, taking care to form neatly wrapped layers.
4. After installing cable, band brake is used to prevent bird nesting while pulling out cable, when clutch is disengaged.



# **CLUTCH OPERATION**

**WARNING: CLUTCH MUST BE FULLY ENGAGED BEFORE STARTING THE WINCHING OPERATION.**

**To engage clutch:**

1. Move clutch control to engage the clutch.
2. Run the motor in the cable out direction until the drum begins to turn.

**WARNING: DO NOT DISENGAGE CLUTCH UNDER LOAD.**

**To disengage clutch:**

1. Run the winch in the “cable out” direction until the load is off the cable.
2. Move the clutch control to disengage the clutch. The cable may now be spooled off.

## **WINCH OPERATION**

The best way to get acquainted with how your winch operates is to make test runs before you use it. Plan your test in advance. Remember, you hear your winch, as well as see it operate; learn to recognize the sounds of a light steady pull, a heavy pull, and sounds caused by load jerking or shifting. Gain confidence in operating your winch and its use will become second nature with you.

The uneven spooling of cable while pulling a load is not a problem, unless there is a cable pileup on one end of drum. If this happens reverse the winch to relieve the load and move your anchor point further to the center of the vehicle. After the job is done you can unspool and rewind for a neat lay of the cable.

## **MAINTENANCE**

Adhering to the following maintenance schedule will keep your winch in top condition and performing as it should with a minimum of repair.

Drum bushings are oil impregnated with synthetic oil. The drum bushings do not require additional grease.

### **A. WEEKLY**

1. Check the oil level and maintain it to the oil level plug. If oil is leaking out, determine location and repair.
2. Check the pressure relief plug on the gear housing cover and the brake housing cover. Be sure they are not plugged.
3. Lubricate cable with light oil.
4. Apply a high quality lithium grease to clutch spline. Apply band brake to control drum. Declutch drum and apply grease to spline between clutch and drum.

### **B. MONTHLY**

1. Check the winch mounting bolts. If any are missing, replace them and securely tighten any that are loose. Use grade 8 or better bolts.
2. Inspect the cable. If the cable has become frayed with broken strands, replace immediately.

### **C. ANNUALLY**

1. Drain the oil from the winch annually or more often if winch is used frequently.
2. Refill the winch to the oil level plug with all purpose GL-5 oil, (see page 5) for gear lube compatible with your climate.
3. Inspect winch for damage and wear.

# LUBRICATION TABLE

## LUBRICANT TABLE


Lubricant Description*	Temp Range F(C)		
	Min Ambient & Operating	Max Ambient	Max Operating
80W140 Synthetic	-25 (-32)	125 (52)	225 (107)
75W90 Synthetic	-40 (-40)	115 (46)	215 (102)
80W90 Conventional	-20 (-29)	100 (38)	180 (82)
85W140 Conventional	20 (6)	120 (50)	200 (93)
*Use API GL-5 or EP lubricants.			

## TROUBLE SHOOTING GUIDE


CONDITIONS	POSSIBLE CAUSE	CORRECTION
<b>OIL LEAKS FROM WINCH</b>	<ol style="list-style-type: none"> <li>1. Seals damaged or worn.</li> <li>2. Too much oil.</li> <li>3. Damaged o-rings.</li> <li>4. Case drain not connected.</li> </ol>	<ol style="list-style-type: none"> <li>1. Replace seal</li> <li>2. Drain excess oil. Refer to page 6.</li> <li>3. Replace o-rings.</li> <li>4. Connect case drain.</li> </ol>
<b>WINCH RUNS TOO SLOW</b>	<ol style="list-style-type: none"> <li>1. Low flow rate.</li> <li>2. Hydraulic motor worn out.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check flow rate. Refer to HYDRAULIC SYSTEMS performance chart on page 2.</li> <li>2. Replace motor.</li> </ol>
<b>CABLE DRUM WILL NOT FREESPOOL</b>	<ol style="list-style-type: none"> <li>1. Clutch not disengaged</li> </ol>	<ol style="list-style-type: none"> <li>1. Check operation. Refer to Clutch Operation on page 4.</li> </ol>
<b>BRAKE WILL NOT HOLD</b>	<ol style="list-style-type: none"> <li>1. Incorrect directional control valve. (cylinder spool, closed center).</li> <li>2. Excessive hydraulic system back pressure.</li> <li>3. Sprag clutch worn out.</li> </ol>	<ol style="list-style-type: none"> <li>1. Use only a motor spool (open center) directional control valve.</li> <li>2. Reduce system back pressure to less than 100 psi.</li> <li>3. Replace sprag clutch mechanism.</li> </ol>
<b>BRAKE WILL NOT RELEASE</b>	<ol style="list-style-type: none"> <li>1. Brake line disconnected or blocked</li> </ol>	<ol style="list-style-type: none"> <li>1. Repair brake line.</li> </ol>
<b>WINCH WILL NOT OPERATE AT HIGH SPEED</b>	<ol style="list-style-type: none"> <li>1. Shift solenoid not working.</li> </ol>	<ol style="list-style-type: none"> <li>1. Verify shift spool is energized.</li> </ol>
<b>WINCH OPERATES ERRATICALLY ON INHAUL</b>	<ol style="list-style-type: none"> <li>1. Sprag hub is reversed.</li> </ol>	<ol style="list-style-type: none"> <li>1. Install sprag hub correctly.</li> </ol>

## INSTRUCTIONS FOR DISASSEMBLY


1. Remove wire rope from drum.
2. Drain oil from winch by removing (2) plugs #63, removing the lower plug first.
3. When replacing lubricant, use 496 oz of applicable lube for your climate from table on page 5, adding 16 oz at #52 and the remaining at #64.




4. Remove (2) nuts #408b from air cylinder #408a. Air cylinder may now be removed. If needed, mounting bracket #401 may be removed by removing pin #404 from pin #405 and then sliding pin out of mounting bracket. Brake band #6 may be expanded over drum flange to barrel for easiest removal.




5. Remove motor #53 from winch by first disconnecting hydraulic lines (see page 17), solenoid wires, and then remove (4) bolts #36. O-ring #55 may now be removed.
6. Remove brake cover #50 by removing (4) bolts #35. **The cover is spring loaded, use care when removing.** Remove o-ring #54 then springs #69 may be removed; residual oil may be present in the brake housing.
7. Remove piston #13 including o-rings and backup rings #56, #57, #58, and #59 by using a momentary puff of compressed air into the brake port located on top of the end bearing. Capture the piston by placing a shop rag over the opening prior to using air. Capture the piston by placing a shop rag over the opening prior to using air.
8. Remove the sprag brake hub assembly #5, (7) stator plates #14, (6) disc brakes #15, and the spacer #25. The sprag brake hub assembly #5 is not a serviceable part, if damaged a replacement assembly should be ordered.




9. Remove (8) cover bolts #33, cover #12, and o-ring #60.
10. Remove snap ring #67, and sun gear #18 and washer #75.
11. The planetary carrier assembly #2 may now be removed along with (2) spacers #24.
12. Remove second snap ring #67 and intermediate sun gear #17.
13. Planetary carrier assembly #4 may now be removed.



14. Using a nylon strap, support ring gear #22 from a hoist or boom, **this ring gear is heavy**.  
Remove (8) bolts #37 leaving the top most bolt for last. Remove the final bolt while supporting ring gear. Set ring gear aside. Remove the o-ring #61.
15. Remove the output sun gear #19 and spacer #28.




16. Remove the clutch cylinder #407 by removing the (2) cotter keys #404 and (2) pins #406 from either end of the air cylinder #407.
17. The clutch cylinder support bracket #9 can be removed by removing the four bolts #35 and nuts #41 attaching it to the mounting angles.
18. Remove the clutch yoke #29 by removing center pivot bolt #34 and nut #41.



\*CLUTCH YOKE #29 SHOWN REMOVED AND PARTIALLY INSTALLED FOR CLARITY

19. By removing snap ring #67 and ball bearing #30, the input shaft #23 may be removed.
20. To remove the motor end bearing #20, support drum #16 with a nylon strap or chain and hoist. Lift on the drum to tension the strap. Remove (6) bolts #39 and (6) nuts #42 attaching the end bearing to the mounting angles #7 and #8. The motor end bearing #20 will be supported on the output shaft end and may be slid off using a nylon strap and hoist to lift it.



While continuing to support the drum #16, remove the clutch #10, snap ring #68 and spacer #26.


21. The output carrier assembly #23 may be slid from the drum assembly.

22. If required, spacer #27 can be removed from output carrier assembly.


23. The drum #14 is now supported only by the nylon strap and may be removed as needed.

24. Remove drum driver #11 by removing (9) bolts #38.



25. The (2) bushings #31 may be pressed from the drum if replacement is necessary.




To remove gear end bearing #21, from mounting angles #7 and #8, first remove (4) bolts #40 and (4) nuts #42 from each angle. Shaft oil seal #66 and end bearing bushing # 31 can be removed and replaced at this time, if necessary.



# HOSE HOOKUP



# PARTS DRAWING




- NOTES:
1. ITEM 1 - AIRCYLINDER KIT CONTAINS FASTENERS AND CYLINDERS FOR CLUTCH AND BAND BRAKE.
  2. ITEM 63 CONTAINS FASTENERS FOR BRAKE VALVE.

# PARTS LIST

ITEM	QTY	PART NO	DESCRIPTION	ITEM	QTY	PART NO	DESCRIPTION
1	1	256131	AIR CYLINDER KIT	40	8	414815	BOLT- 1-8NC X 4 LG, HXHD, GR8
2	1	296744	INPUT CARRIER ASSEMBLY	41	5	418069	NUT-1/2-13NC HEX REG
3	1	296693	OUTPUT CARRIER ASSEMBLY	42	14	418115	NUT-1-8NC HEX REG
4	1	296705	INTERMEDIATE CARRIER ASSEMBLY	43			NOT USED
5	1	296688	SPRAG BRAKE ASSEMBLY	44	1	432018	FITTING JIC O-RING EL
6	1	299752	BAND BRAKE	45	4	432023	FITTING JIC O-RING NIPPLE
7	1	303160	FRAME RAIL-LH	46	1	432048	FITTING JIC SWIVEL TEE
8	1	303161	FRAME RAIL-RH	47	2	432049	FITTING JIC BRANCH TEE
9	1	312576	SUPPORT BRACKET, AIR CYLINDER	48	1	432053	FITTING JIC PIPE NIPPLE
10	1	324513	CLUTCH	49	1	432054	FITTING JIC SWIVEL EL
11	1	324515	DRUM DRIVER	50	1	438043	BRAKE COVER
12	1	328175	COVER-GEAR END	51			NOT USED
13	1	330016	PISTON-BRAKE	52	2	456008	RELIEF FITTING
14	7	330017	STATOR PLATE-BRAKE	53	1	458169	MOTOR
15	6	330018	FRICTION PLATE-BRAKE	54	1	462063	O-RING 2-165
16	1	332254	DRUM	55	1	462081	O-RING 2-159
17	1	334226	GEAR-INTERMEDIATE SUN	56	1	462082	O-RING 2-358
18	1	334242	GEAR-INPUT SUN	57	1	462083	BACKUP RING 8-357
19	1	334232	GEAR-OUTPUT SUN	58	1	462084	O-RING 2-362
20	1	338404	BEARING SUPPORT, MOTOR END	59	1	462085	BACKUP RING 8-362
21	1	338405	BEARING SUPPORT-GEAR END	60	1	462093	O-Ring 2-275
22	1	338411	RING GEAR	61	1	462097	ORING 2 -284
23	1	357539	SHAFT-INPUT	62	1	468016	PIPE PLUG
24	2	362301	SPACER	63	2	468041	PLUG
25	1	362305	SPACER-BRAKE	64	1	468042	REDUCER
26	3	362319	SPACER-OUTPUT SHAFT	65	1	486099	OIL SEAL
27	1	362323	SPACER-BEARING	66	1	486100	OIL SEAL
28	1	362324	SPACER-OUTPUT SUN	67	3	490068	RETAINING RING 5100-125
29	1	370062	YOKE-CLUTCH	68	1	490069	RETAINING RING 5100-500
30	1	402142	BEARING BALL	69	12	494129	BRAKE SPRING
31	1	412143	BUSHING	70	1	509137	HOSE
32	1	412144	BUSHING-MOTOR END	71	1	509140	HOSE
33	8	414521	CAPSCREW-1/2-13NCX1LG HXHD	72	3	509141	HOSE
34	1	414545	CAPSCREW-1/2-13NCX3.5LG,HXHD,Z/P,GR5	73	1	514025	U-BOLT
35	10	414556	BOLT-1/2-13NCX1.75,HXD,GR5	74	1	516048	C'BAL VALVE
36	4	414561	CAPSCREW-1/2-13NCX1.25 HXHD GR.5	75	1	518080	WASHER-THRUST
37	8	414658	BOLT-5/8-11NCX1.5LG,HXHD,Z/P,GR.5	76	1	357538	SHAFT-OUTPUT
38	9	414665	BOLT-5/8-11NCX2LG,HXHD,Z/P,GR.5	77	2	412150	BUSHING, DRUM
39	6	414814	BOLT- 1-8NC X 4.5 LG, HXHD, GR8				




# AIR CYLINDER KIT #256131 PARTS LIST



ITEM	QTY	PART NO	DESCRIPTION
201	1	408422	MOUNTING BRACKET
202	2	418067	NUT-1/2-20NF HEX JAM
203	2	418223	WASHER-1/2 USS FLAT
204	3	424005	COTTER PIN- 1/8 DIA X 1 LG
205	1	424027	CLEVIS PIN-1/2 SHAFT DIA X 1 1/2 LG
206	2	424205	CLEVIS PIN-1/2 SHAFT DIA X 1 23/64 LG
207	1	433031	AIR CYLINDER
208	1	433032	AIR CYLINDER
209	1	448108	EYE BOLT

# DIMENSIONAL DRAWING

Bolt Size (inches)	Thds Per Inch	Bolt Torque (ft-lb)	
		SAE Grade 5	SAE Grade 8
7/16	14	54	78
1/2	13	78	119
5/8	11	154	230
3/4	10	257	380
7/8	9	382	600
1	8	587	700



# WILDCAT<sup>®</sup>

# WINCH SERIES

By  **RAMSEY  
WINCH<sup>®</sup>**

## Limited Warranty

RAMSEY WINCH warrants each new RAMSEY Wildcat Winch to be free from defects in material and workmanship for a period of two (2) years from the date of purchase. Our new two year limited warranty is standard equipment on all Wildcat Winches manufactured after July 4th, 2014, and is also available for all Wildcat series winches currently in inventory at authorized distributors if the model and serial numbers are submitted to Ramsey Winch by August 30, 2014. End users who have purchased a winch since June 1, 2014, are also eligible for the two year warranty with purchase date, serial number, and model number submitted to an approved Wildcat Distributor by August 30, 2014.

Warranty General. The obligation under this warranty, statutory or otherwise, is limited to the replacement or repair at the Manufacturer's factory, or at a point designated by the Manufacturer, of such part that shall appear to the Manufacturer, upon inspection of such part, to have been defective in material or workmanship. This warranty does not obligate RAMSEY WINCH to bear the cost of labor or transportation charges in connection with the replacement or repair of defective parts, nor shall it apply to a product upon which repairs or alterations have been made unless authorized by the Manufacturer, or for equipment misused, neglected or which has not been installed correctly.

To the fullest extent permitted by applicable law, the following are hereby excluded and disclaimed: 1. All warranties of fitness for a particular purpose; 2. All warranties of merchantability; 3. All claims for consequential or incidental damages. There are no warranties that extend beyond the description that appears on the face hereof. Some states do not allow the above exclusions or disclaimers in consumer transactions and as such this disclaimer/exclusion may not apply to your particular case. To the extent such warranties of fitness for a particular purpose or merchantability are deemed to apply to this product, they exist for only so long as the express limited warranty elsewhere set forth is in existence.

RAMSEY WINCH whose policy is one of continuous improvement, reserves the right to improve its products through changes in design or materials as it may deem desirable without being obligated to incorporate such changes in products of prior manufacture.

If field service at the request of the Buyer is rendered and the fault is found not to be with RAMSEY WINCH's product, the Buyer shall pay the time and expense of the field representative. Bills for service, labor or other expenses that have been incurred by the Buyer without approval or authorization by RAMSEY WINCH will not be accepted.

This Warranty gives you specific legal rights and you may also have other legal rights, which vary from state to state.



**Ramsey Winch Company**

Post Office Box 581510

Tulsa, Oklahoma 74158-1510

Telephone: (#918) 438-2760 FAX: (#918) 438-6688