




OPERATING, SERVICE AND MAINTENANCE MANUAL



MODEL HD-234 LEVER OPERATED INDUSTRIAL LOW-MOUNT WINCHES



**CAUTION: READ AND UNDERSTAND THIS MANUAL BEFORE
INSTALLATION AND OPERATION OF WINCH. SEE WARNINGS!**

NOTES

TABLE OF CONTENTS

INTRODUCTION	4
WARRANTY INFORMATION	4
SPECIFICATION	4
TECHNIQUES OF OPERATION	5
WARNINGS	5
WINCH MAINTENANCE	6
WINCH MOUNTING	6
CABLE INSTALLATION	6
HYDRAULIC SYSTEMS/PERFORMANCE CHARTS	7
TYPICAL LAYOUT/HYD. SYSTEM DIAGRAM	7
TROUBLE SHOOTING GUIDE	8
INSTRUCTIONS FOR OVERHAUL OF RAMSEY MODEL HD-234 WINCH	
DIS-ASSEMBLY	9-12
RE-ASSEMBLY	12-15
DIMENSIONAL DRAWING	17
PARTS LIST AND PARTS DRAWING	18-19
LIMITED WARRANTY	BACK COVER

RAMSEY WINCH MODEL HD-234

PLEASE READ THIS MANUAL CAREFULLY.

This manual contains useful ideas in obtaining the most efficient operation from your Ramsey Winch, and safety procedures one needs to know before operating a Ramsey Winch.

WARRANTY INFORMATION

Ramsey Winches are designed and built to exacting specifications. Great care and skill go into every winch we make. If the need should arise, warranty procedure is outlined on the back of your self-addressed postage paid warranty card. Please read and fill out the enclosed warranty card and send it to Ramsey Winch Company. If you have any problems with your winch, please follow instructions for prompt service on all warranty claims. Refer to back page for limited warranty.

SPECIFICATIONS: CONFORMS TO SAE J706*

Rated Line Pull (lbs.)		8,000			
(kg)		3,620			
Gear Reduction		34:1			
Weight HD-234		110lbs. (50 kg)			
HYD-234		105 lbs. (48 kg)			
LAYER OF CABLE		1	2	3	4
*Rated line pull	lbs.	8,000	6,700	5,700	5,000
per layer	kg	3,620	3,030	2,610	2,290
**Long Drum	ft.	25	60	95	140
Cable capacity	m	8	18	30	43
**Short "Y" Drum	ft.	15	30	55	75
Cable capacity	m	4	9	16	22
**Line speed	FPM	28	34	39	44
	MPM	8,6	10,1	11,7	13,4
* Winch only conforms to SAE J706. For SAE qualification of mounting angles, if applicable, consult Ramsey Engineering ** These specifications are based on recommended wire rope of 3/8 inch diameter extra improved plow steel or equivalent.					

NOTE: The rated line pulls shown are for the winch only. Consult the wire rope manufacturer for wire rope ratings.

TECHNIQUES OF OPERATION

The best way to get acquainted with how your winch operates is to make test runs before you actually use it. Plan your test in advance. Remember, you hear your winch, as well as see it operate. Get to recognize the sounds of a light steady pull, a heavy pull, and sounds caused by load jerking or shifting. Gain confidence in operating your winch and its use will become second nature with you.

The uneven spooling of cable, while pulling a load, is not a problem, unless there is a cable pileup on one end of drum. If this happens reverse the winch to relieve the load and move your anchor point further to the center of the vehicle. After the job is done you can unspool and rewind for a neat lay of the cable.

When pulling a load where there is even a remote chance of cable failure, place a blanket, jacket or tarpaulin over the cable about six feet behind the hook. This will slow the snap back of a broken cable and could prevent serious injury.

NOTE: The Ramsey level winder is an available accessory for tightly respooling unloaded cable onto the drum.

The winch clutch allows rapid unspooling of the cable, from cable drum, for holding onto a load. The clutch is operated by the lever located on the clutch housing of winch.

1. **TO DISENGAGE CLUTCH**, run the winch in the reverse (reel out) direction until load is off the cable. Grasp lever and push toward the drum to the “OUT” position. The lever is latched “OUT” by ball and detent in jaw clutch and drum shaft. The cable may now be pulled from cable drum by hand.
2. **TO ENGAGE CLUTCH**, pull handle away from the drum to the “IN” position, while rotating drum, until clutch jaws engage with drum jaws. Clutch must be totally engaged during winching operations. The lever is latched “IN” by ball and detent in jaw clutch and drum shaft. The plastic plug in top of clutch housing may be removed for inspection of clutch, to assure total engagement.



WARNINGS

CLUTCH MUST BE TOTALLY ENGAGED BEFORE STARTING THE WINCHING OPERATION.

DO NOT DISENGAGE CLUTCH UNDER LOAD.

STAY OUT FROM UNDER AND AWAY FROM RAISED LOADS.

STAND CLEAR OF CABLE WHILE PULLING. DO NOT TRY TO GUIDE CABLE.

DO NOT EXCEED MAXIMUM LINE PULL RATINGS SHOWN IN TABLE.

DO NOT USE WINCH TO LIFT, SUPPORT, OR OTHERWISE TRANSPORT PEOPLE.

A MINIMUM OF 5 WRAPS OF CABLE AROUND THE DRUM BARREL IS NECESSARY TO HOLD THE LOAD. CABLE SETSCREW IS NOT DESIGNED TO HOLD LOAD.

WINCH MAINTENANCE

Adhering to the following maintenance schedule will keep your winch in top condition and performing as it should with a minimum of repair.

A. WEEKLY

1. Check the oil level and maintain it to the oil level plug. If oil is leaking out, determine location and repair.
2. Check the pressure relief plug in top of the gear housing, yoke, lubricate shifter forks and groove of jaw clutch per diagram below. Be sure that it is in good operating condition so that hot oil gases may escape.
3. Lubricate cable with light oil.

B. MONTHLY

1. Remove inspection plug from top of clutch housing. Lubricate the grease fittings on the clutch housing.
2. Lubricate shifter yoke forks and groove of jaw clutch per Figure 1. Run winch and lubricate jaw clutch groove for one drum revolution. Any good grade of **moly-disulfide containing grease** is acceptable and can be obtained from Ramsey by ordering kit #251333.
3. Check the action of the sliding clutch ensure it is fully engaging and disengaging with the cable drum. To observe if the clutch is fully engaging, remove the plastic plug in top of the housing. If clutch is not fully engaging:
 - Inspect clutch shifter assembly parts, check for damage or excessive wear and replace by ordering Ramsey kit #251334.
 - Observe the jaws on both the clutch and cable drum, checking for rounding of the driving faces. If rounding has occurred they should be replaced immediately.
4. Check the winch mounting bolts. If any are missing, replace them and securely tighten any that are loose. Make sure to use only SAE grade 5 bolts or better.
5. Inspect the cable. If the cable has become frayed with broken strands, replace immediately.

NOTE: SHOWN UNGREASED FOR CLARITY




FIGURE 1

(CUT AWAY FOR
DEMONSTRATION)

C. ANNUALLY

1. Remove clutch housing and inspect yoke forks. If they are worn or damaged, order kit #251334 for a replacement yoke. Remove clutch housing and grease jaw clutch groove and shifter yoke forks as shown in Figure 1. Any good grade **moly-disulfide containing grease** is acceptable and can be obtained by ordering Ramsey kit #251333.
2. Drain the oil from the winch annually or more often if winch is used frequently.
3. Fill the winch to the oil level plug with clean kerosene. Run the winch a few minutes with no load in the reel in direction. Drain the kerosene from the winch.
4. **Refill the winch to the oil level plug with Phillips SMP 80W-90, Mobil HD 80W-90, Shell Spirax HD 80W-90, or CITGO MP 80W-90 gear oil only.**
5. Inspect frame and surrounding structure for cracks or deformation.
6. Gear wear can be estimated by rocking the drum back and forth and if necessary drain oil and remove cover for closer inspection.

WINCH MOUNTING

It is most important that this winch be mounted securely so that the three major sections (clutch housing end, cable drum, and gear housing end) are properly aligned. All standard model HD-234 series winches are furnished with recommended mounting angles. Angle size is 1/4 x 2-1/2 x 2-1/2 x 36" long high strength steel angle.

CABLE INSTALLATION

1. Unwind cable by rolling it out along the ground to prevent kinking. Securely wrap end of cable, opposite hook, with plastic or similar tape to prevent fraying.
2. Insert the end of cable, opposite hook end, into the 7/16" dia. hole in drum barrel. Secure cable to drum barrel, using setscrew furnished with winch.
TIGHTEN SETSCREW SECURELY.
3. Carefully run winch in the "reel-in" direction. Keeping tension on end of cable, spool all the cable onto the cable drum, taking care to form neatly wrapped layers.

HYDRAULIC SYSTEMS


Refer to performance charts, below, to properly match your hydraulic system to the HD-234 winch performance. The charts consist of:

1. Line pull (lbs.) first layer vs. working pressure (PSI). STATIC (solid line) refers to hoisting a suspended load from rest; DYNAMIC (dashed line) refers to maintaining the motion of a moving load.
2. Line speed, first layer (FPM) vs. gallons per minute (GPM).


Performance based on a motor displacement of 3.6 cubic inches with 15 GPM maximum flow rate.

HD-234 PERFORMANCE

8,000 LB. DUTY RATING - 34:1 GEAR RATIO



TYPICAL LAYOUT




Troubleshooting Guide

CONDITION	POSSIBLE CAUSE	CORRECTION
CLUTCH INOPERATIVE OR BINDS UP	1. Dry or rusted shaft. 2. Bent yoke or linkage. 3. Clutch jaws are in contact.	1. Clean and lubricate 2. Replace yoke or shaft assembly. 3. See <i>Techniques of Operation</i> .
OIL LEAKS FROM HOUSING	1. Seal damaged or worn. 2. Too much oil. 3. Damaged gasket.	1. Replace seal. 2. Drain excess oil. Refer to <i>Techniques of Operation</i> . 3. Replace gasket.
WINCH RUNS TOO SLOW	1. Hydraulic motor worn out. 2. Low flow rate.	1. Replace motor. 2. Check flow rate. Refer to Hydraulic Systems flow chart.
CABLE BIRDNESTS WHEN CLUTCH IS DISENGAGED	1. Drag brake disc worn.	1. Replace discs.
HYDRAULIC FLUID LEAKS OUT HOLE IN MOTOR ADAPTER	1. Hydraulic motor shaft seal damaged.	1. Replace seal.


INSTRUCTIONS FOR OVERHAUL OF RAMSEY MODEL HD-234

DIS-ASSEMBLY


1. Drain oil from gear housing by removing plug (item #34) from bottom of gear housing. Remove plugs (items #32 & #33) from top of gear housing.




2. Remove clutch housing (item #7) and clutch (item #3) from winch assembly.
3. Remove two keys (item #29) from keyways. A screwdriver can be used, at notch, to aid in the removal of keys. Once keys have been removed, drum (item #5) and thrust washer (item #42) can be removed from drum shaft.



4. Remove coupling (item #25) from adapter (item #1) by unscrewing four screws (item #21). Replace adapter seal (item #42) and gas-ket (item #30).




5. Remove bearing cap (item #2) from gear housing by unscrewing four capscrews (item #20). Remove worm (item #14) and bearings (item #17) from gear housing. Use soft hammer to gently tap input end of worm and drive worm and bearing from gear housing. Once worm has been removed from housing, bearing can be pressed from end of worm. Check for signs of wear or damage to worm (item #14) and bearing (item #17). Replace if necessary. Drag brake disc (item #26) and spring (item #40) should be examined and replaced if necessary.




6. Remove gear housing cover (item #4) from gear housing (item #8) by unscrewing capscrews (item #20). Thread two of the capscrews into the two tapped holes of cover and tighten. This will pull the cover loose from the gear housing.

Remove cover gasket (item #28) and pull shaft (item #13), with gear attached, and thrust washer (item #41) from gear housing.




7. Check for signs of wear on gear teeth. If replacement of gear is necessary, replace as follows:


- a) Press gear (item #6) from shaft (item #13).
- b) Examine shaft keys and keyways. If distortion of keys and/or keyways is evident, shaft and keys should be replaced.
- c) Use a soft hammer to gently tap keys (item #30) into keyways. Press gear (item #6) over shaft and keys. Gear must be centered over keys.




8. Remove seal (item #38) from back of gear housing (item #8). Press bushing (item #19) from gear housing. Press new bushing and seal back into place.




9. Check drum bushings (item #16) for signs of wear. Replace if necessary by pressing old bushings from drum. Press new ones into place.



10. Check clutch housing bushing (item #18) for wear. If necessary, remove old bushing and press new bushing into place. Check yoke (item #15) for damage. Yoke should be firmly attached with setscrew (item #24). Apply grease to lube fittings (item #31) to lubricate clutch shifter shaft (item #12).




11. Check cover bushing (item #18) for signs of wear. If necessary remove old bushing and press bushing into place.



RE-ASSEMBLY

12. Apply grease to end of shaft, opposite gear. Apply grease to bushing in gear housing (item #8). Place greased end of shaft through thrust washer (item #42) and bushing in gear housing (item #8). Place gasket (item #28) onto gear housing cover (item #4). Apply grease to gear end of shaft and cover bearing. Place cover onto shaft and secure to housing with ten capscrews (item #20). **Tighten capscrews to 8 ft-lbs. (10.8 Nm) each.**




13. Press bearing (item #17) onto worm (item #14) Note:


Be sure that thick shoulder of bearing's outer race (side with manufacturer's name and part number) is out, away from worm threads.

Press bearing and worm into gear housing. Slip gasket (item #27) onto bearing cap (item #2).

Use four capscrews (item #20) to secure cap to gear housing. **Tighten capscrews to 8 ft-lbs. (10.8 Nm) each.**




14. Press bearing (item #17) onto worm and into gear housing. **Note:** Be sure that thick shoulder of bearing's outer race (side with manufacturer's name and part number) is out, away from worm threads.




15. Place gasket (item #27) onto adapter (item #1). Slide seal (item #37) onto worm. Slide tapered end of coupling (item #25) over end of worm shaft. Attach adapter and coupling to gear housing using four screws (item #21).

Tighten screws to 12 ft-lbs. (16.3 Nm) each.



16. Place winch with gear housing cover down on work bench. Drum shaft should be in vertical position. Slide thrust washer (item #42) over drum shaft and slide downward until washer rests on gear housing. Set springs (item #40) into pockets of gear housing with drag brakes (item #26) on top of springs. Slide drum assembly (item #5) onto drum shaft with drum jaws upward.




17. Place thrust washer (item #42) over end of drum shaft and slide downward until space rests on drum. Press drum downward to compress springs in gear housing.

Insert keys (item #29) into keyways with sharp edge of keys pointing outward and notched end of keys upward. A rubber or brass mallet will be needed to gently tap keys into position.


Apply grease to keys and end of shaft. Place jaw clutch (item #3) over end of shaft and slide jaw clutch over keys.

Set clutch housing (item #7) over end of drum shaft. Pull jaw clutch (item #3) upward, toward clutch housing, enough to allow yoke, in clutch housing, to fit properly in groove around jaw clutch.





18. Insert plug (item #34) into bottom of gear housing. Permatex may be applied to threads to help prevent leakage.

Pour 3/4 pint of **Phillips SMP 80W-90, Mobil HD 80W-90, Shell Spirax HD 80W-90, or CITGO MP 80W-90 gear oil only** into housing through hole in top of housing. Insert relief fitting (item #32) into reducer (item #33). Reducer should then be placed into hole on top of gear housing. Tighten fitting and reducer securely.



DRUM SIZE	DIM A	DIM B	DIM C
STD	11,31 287,3	13,12 333,3	20,27 514,8
Y	6,31 160,2	8,12 206,2	15,27 387,8






Model HD-234 Lever

PARTS LIST MODEL HD-234

Item No.	Qty.	Parts No.	Description	Item No.	Qty.	Parts No.	Description
1	1	300039	ADAPTER	21	4	414835	SCREW-1/4-20NCX1-1/4,HXSOC,ND STRIP
2	1	316083	BEARING CAP	22	1	416040	SETSCREW - 5/16-18NC X 1/4 HX SOC HD
3	1	324161	CLUTCH - JAW	23	1	416059	SETSCREW - 3/8-16NC X 1/2 HX SOC HD CUP
4	1	328134	COVER	24	1	416084	SETSCREW - 1/4-20NC X 1/2 SQHD CUP
5	1	332105	DRUM - STD	25	1	431007	COUPLING - HYDRAULIC MOTOR
	1	332007	DRUM - "y"	26	2	438014	DISC BRAKE
6	1	334183	GEAR - R.H. WORM	27	2	442184	GASKET
7	1	338003	CLUTCH HOUSING	28	1	442205	GASKET
8	1	338273	GEAR HOUSING	29	2	450006	KEY
9			NOT USED	30	4	450016	KEY
10	1	342024	KEY	31	2	456006	FITTING - LUBRICATION
11	1	494130	TORSION SPRING	32	1	456008	RELIEF FITTING
12	1	356902	SHIFTER SHAFT	33	1	468002	REDUCER
13	1	357479	DRUM SHAFT - STD.	34	1	468011	PIPE PLUG
	1	357481	DRUM SHAFT - "y"	35	2	472006	PLASTIC CAP
14	1	368205	WORM - R.H.	36	1	472013	PLUG
15	1	370055	YOKE	37	1	486009	OIL SEAL
16	1	400001	BALL POPPET	38	1	486017	OIL SEAL
17	2	402002	BEARING	39	1	494001	SPRING POPPET
18	4	412003	BUSHING	40	2	494002	SPRING
19	1	412045	BUSHING	41	1	518014	THRUST WASHER
20	14	414045	CAPSCREW - 1/4-20NC X 7/8 HX HD GR5 ZIP	42	2	518015	THRUST WASHER

KITS AND MAINTENANCE PARTS

121818 & 124094



KITS AND MAINTENANCE PARTS

121818 & 124094

				WINCH(ES)		KITS					
ITEM #	QTY.	PART NUMBER	DESCRIPTION	121818	124094	222056	207031	248055	246040	250507	283082
1	1	300039	ADAPTER								
2	1	316083	CAP-BRG								
3	1	324161	JAW CLUTCH			X					
4	2	330010	SHOE-DRAG BRK				X				
5	1	364017	STRAP-SHIP,1/8 X 1 X 14 LG								
6	1	368205	WORM-GEAR								
7	2	402002	BEARING-BALL							X	
8	1	413013	COVER-HYD ADP								
9	4	414045	CAPSCREW-1/4-20NCX7/8 LG. HEX HD								
10	2	414279	CAPSCREW-3/8-16NCX3/4 LG,HXHD								
11	2	414521	CAPSCREW-1/2-13NCX1LG HXHD								
12	4	414835	SCREW-1/4-20NCX1-1/4,HXSOC								
13	1	431007	COUPLING-HYD								X
14	2	442184	GASKET-BRG CAP						X	X	
15	2	450006	KEY-BARTH								
16	1	456008	RELIEF FIT-1/8-27PFT								
17	1	468002	RED-3/8-1/8NPTF								
18	1	468011	PIPE PLUG-3/8-18NPTF								
19	1	486009	OIL SEAL						X	X	
20	2	494002	SPRING				X				
21	1	518014	THRUST WASHER					X			
22	1	338003	HOUSING								
23	1	342024	KEY			X					
24	1	356902	SHAFT			X					
25	1	370055	YOKE			X					

KITS AND MAINTENANCE PARTS

121818 & 124094

ITEM #	QTY.	PART NUMBER	DESCRIPTION	WINCH(ES)		KITS					
				121818	124094	222056	207031	248055	246040	250507	283082
26	6	412045	BUSHING					X			
27	1	416084	SETSCREW-1/4-20NCX1/2 SQHD			X					
28	2	456006	FITTING-LUBE								
29	1	472006	CAP-PLAST			X					
30	1	472013	PLUG								
31	1	494130	SPRING-TORSION			X					
32	1	328134	COVER-GEAR HSG								
33	1	334183	WORM GEAR - RH							X	
34	1	338273	HOUSING-GEAR								
35	1	357479	SHAFT-DRUM							X	
36	10	414045	CAPSCREW-1/4-20NCX7/8 LG. HEX HD								
37	1	442205	GASKET						X	X	
38	4	450016	KEY							X	
39	1	468018	PIPE PLUG								
40	1	486017	OIL SEAL						X	X	
41	1	518015	THRUST WASH					X			
42	1	256181	ASSEMBLY-SPRING ROLLER TENSIONER								
43	1	332105	DRUM								
44	1	416059	SETSCREW3/8-16NCX1/2 HX SOCK HD CUP								
45	1	257658	BOLT-MOUNTING SET W/WINCH								

LIMITED WARRANTY

RAMSEY WINCH warrants each new RAMSEY winch to be free from defects in material and workmanship for a period of one (1) year from date of purchase.

The obligation under this warranty, statutory or otherwise, is limited to the replacement or repair at the Manufacturer's factory, or at a point designated by the Manufacturer, of such part that shall appear to the Manufacturer, upon inspection of such part, to have been defective in material or workmanship.

This warranty does not obligate RAMSEY WINCH to bear the cost of labor or transportation charges in connection with the replacement or repair of defective parts, nor shall it apply to a product upon which repair or alterations have been made, unless authorized by Manufacturer, or for equipment misused, neglected or which has not been installed correctly.

RAMSEY WINCH shall in no event be liable for special or consequential damages. RAMSEY WINCH makes no warranty in respect to accessories such as being subject to the warranties of their respective manufacturers.

RAMSEY WINCH, whose policy is one of continuous improvement, reserves the right to improve its products through changes in design or materials as it may deem desirable without being obligated to incorporate such changes in products of prior manufacture.

If field service at the request of the Buyer is rendered and the fault is found not to be with RAMSEY WINCH's product, the Buyer shall pay the time and expense to the field representative. Bills for service, labor or other expenses that have been incurred by the Buyer without approval or authorization by RAMSEY WINCH will not be accepted

See warranty card for details.



RAMSEY WINCH COMPANY

P.O. Box 581510 • Tulsa, Oklahoma 74158-1510 USA

Phone: (918) 438-2760 • Fax: (918) 438-6688

www.ramsey.com